

Axial Piston Fixed Motor A2FM

RE 91001/06.2012 1/46 Replaces: 09.07

Data sheet

Series 6 Size Nominal pressure/Maximum pressure 5 315/350 bar 10 to 200 400/450 bar 250 to 1000 350/400 bar Open and closed circuits

Contents

Ordering code for standard program	2
Technical data	4
Dimensions	11
Flushing and boost pressure valve	34
Pressure-relief valve	36
Counterbalance valve BVD and BVE	38
Speed sensors	42
Installation instructions	44
General instructions	46

Features

- Fixed motor with axial tapered piston rotary group of bentaxis design, for hydrostatic drives in open and closed circuits
- For use in mobile and stationary applications
- The output speed is dependent on the flow of the pump and the displacement of the motor.
- The output torque increases with the pressure differential between the high-pressure and the low-pressure side.
- Finely graduated sizes permit far-reaching adaptation to the drive case
- High power density
- Small dimensions
- High total efficiency
- Good starting characteristics
- Economical design
- One-piece tapered piston with piston rings for sealing



Ordering code for standard program

	A2F		M			/		6			W		-		V								
0	1 02	03	04	05			(06	07	7	08			C	9	10		11		12	13	14	1
	Hydraulic																					<u>,</u>	
	Mineral oil				sizes	\$ 250) to		-						-	life be	earir	igs "l	_" (v	vitho	ut cod	e)	
)1	HFB, HFC	; hydra	ulic fluic	ł									ithou								<u> </u>		<u> </u>
									Size	s 25	0 to	1000) (on	ly in	com	ibina	tion	with	long	-lite l	bearing	gs "L")	E
	Axial pisto	on unit																					
)2	Bent-axis	design,	fixed																				A2
	Drive shaf	t beari	na												5	to 20	00	250	to 5	500	710 te	o 1000	
	Standard			ut coo	de)											•			•			_	
)3	Long-life b				-											-			•			•	L
																				l			
1	Operating					E 01(N
)4	Motor (plu	ig-in mo		⊏, se	e R	2 910	508)																IV
	Size (NG)																						-
		disnla	cement	, see	_				· ·		r					r		r					
5	Geometric								I			~ ^		107	125	160	100	اممما	າະດ	255	= 0 0 74	011000	
)5	Geometric			12	16	23	28	32	45	56	63	80	90	107	125	100	180	200	250	355	500/7		<u>'</u>
)5				12	16	23	28	32	45	56	63	80	90	107	125		180	200	250	355	500[7]		<u>'</u>
	Geometric Series			12	16	23	28	32	45	56	63	80	90	107	125		180	200	250	355	500[7]		′」 6
	Series			12	16	23	28	32	45	56	63	80	90	107	123		180	200	250	333	500[7]		-
				12	16	23	28	32	45	56	63	80	90						230	335	500[7]		6
06	Series			12	16	23	28	32	45	56	63	80	90			NG1	0 to		230	<u> </u>	500[7]		6
06	Series			12	16	23	28	32	45	56	63	80	90			NG1 NG2	0 to 200	180					6
06	Series			12	16	23	28	32	45	56	63	80	90			NG1	0 to 200	180					6
)6	Series Index Direction	of rotat	5 10 ion	·			28	32	45	56	63	80	90			NG1 NG2	0 to 200	180					6 1 3 0
)6	Series	of rotat	5 10 ion	·			28	32	45	56	63	80	90			NG1 NG2	0 to 200	180					6 1 3 0
D5 D6 D7 D8	Series Index Direction	of rotat	5 10 ion	·			28	32	45	56	63	80	90			NG1 NG2	0 to 200	180					6 1 3 0
06	Series Index Direction of Viewed or	of rotat	5 10 ion shaft, bio	·			28	32	45	<u>56</u>	<u>63</u>	80				NG1 NG2	0 to 200	180					6 1 3 0 W
D6 D7 D8	Series Index Direction of Viewed or Seals FKM (fluor)	of rotat n drive s r-caouto	5 10 ion shaft, bio	direct	tiona											NG1 NG2 NG5	0 to 200 5 anc	180) to ⁻	1000		· · · · · · · · · · · · · · · · · · ·	-
)6)7)8	Series Index Direction of Viewed or Seals FKM (fluo) Drive shaf	of rotat of rotat of rotat	5 10 ion shaft, bio	·	tiona	12	16		28	32	45	56	63	80	90	NG1 NG2 NG5	0 to 200 3 and	180 I 250) to ⁻	1000		o 1000	
06	Series Index Direction of Viewed or Seals FKM (fluor)	of rotat a drive s r-caoute ts naft	5 10 ion shaft, bio	direct	tiona	12	16	23		32			63	80		NG1 NG2 NG5	0 to 200 5 anc	180 I 250 160) to ⁻	1000	250 t	o 1000	6 1 3 0
)6)7)8	Series Index Direction of Viewed or Seals FKM (fluor Drive shaf Splined sh DIN 5480	of rotat o drive s r-caouto ts naft	5 10 ion shaft, bio	direct 5 - -	tiona 10 •	12	16 • -	23	28 •	32 • -	45 - •	56 •	63 • -	80	90	NG1 NG2 NG5	0 to 200 5 and 125 • -	180 I 250) to - 180 • -	1000 200 -	250 t	o 1000 -	6 6 1 3 0 0 V V A Z
)6)7)8	Series Index Direction of Viewed or Seals FKM (fluor Drive shaf Splined sh	of rotat of rotat of rotat of rotat of rotat	5 10 ion shaft, bio	direct	tiona 10 •	12 •	16 • -	23 • •	28 • •	32 • -	45 - • -	56 •	63 • -	80 •	90 • -	NG1 NG2 NG5	0 to 200 i anc 125 • -	180 I 250 I 60 •) to -	10000 2000 • -	250 t	o 1000 - -	6 1 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
)6)7)8	Series Index Direction of Viewed or Seals FKM (fluor Drive shaf Splined sh DIN 5480 Parallel ke DIN 6885	of rotat a drive s r-caouto ts paft	5 10 ion shaft, bio	direct 5 - -	10 • •	12 • •	16 • -	23	28 •	32 • -	45 - •	56 •	63 • -	80	90 • -	NG1 NG2 NG5	0 to 200 5 anc 125 • • •	180 I 250 160	180 • -	10000 2000 0 - 0 - -	250 t	o 1000 - - -	С 6 1 3 С V V Р Г Г Г
)6)7)8	Series Index Direction of Viewed or Seals FKM (fluo) Drive shaf Splined st DIN 5480 Parallel ke	of rotat a drive s r-caouto ts paft	5 10 ion shaft, bio	direct	tiona 10 •	12 •	16 • -	23 • •	28 • •	32 • -	45 - • -	56 •	63 • -	80 •	90 • -	NG1 NG2 NG5	0 to 200 i anc 125 • -	180 I 250 I 60 •) to -	10000 2000 • -	250 t	o 1000 - -	 _
06 07 08	Series Index Direction of Viewed or Seals FKM (fluor Drive shaf Splined sh DIN 5480 Parallel ke DIN 6885	of rotat a drive s r-caoute ts naft wyed sha	5 10 ion shaft, bio chouc)	direct	10 • •	12 • •	16 • -	23 • •	28 • •	32 • -	45 - • -	56 •	63 • -	80 •	90 • -	NG1 NG2 NG5	0 to 200 5 anc 125 • • •	180 1 250 160 • • • •	180 • -	1000 200 - - - - - -	250 t	o 1000 - - -	6 1 3 0
)6)7)8	Series Index Direction of Viewed or Seals FKM (fluor Drive shaf Splined sh DIN 5480 Parallel ke DIN 6885 Conical sh	of rotat a drive s r-caouto ts naft naft naft ¹⁾ flanges	5 10 ion shaft, bio chouc)	direct	10 • •	12 • •	16 • -	23 • •	28 • •	32 • -	45 - • -	56 •	63 • -	80 •	90 • -	NG1 NG2 NG5	0 to 200 5 anc 125 • • •	180 1 250 160 • • • •	180 - - - -	1000 200 - - - - - -	250 t	o 1000 - - -	

 \bullet = Available

O = On request

– = Not available

= Preferred program

1) Conical shaft with threaded pin and woodruff key (DIN 6888). The torque must be transmitted via the tapered press fit.

Ordering code for standard program

1 02 03 04 05 Port plates for service lines ²⁾ SAE flange ports A and B at rear SAE flange ports A and B at side, opposite	01		06					_	V							
SAE flange ports A and B at rear SAE flange ports					07	08			09	10	11	1	12	13	14	15
SAE flange ports A and B at rear SAE flange ports																
A and B at rear SAE flange ports		-	5		23	_	45	56,63	1 1		160-180	200	250	355-500		
SAE flange ports			-	-		•	•	•		•	•			•		010
		7	-	-	-	-	-	-	-	-	-	-	-	•	-	017
A and B at side, opposite	02		-	-	•	•	•	•		•	•	-	•	-	-	02
		7 9	-	-	-	-	•			•	•	-	•	-	-	02
Threaded ports A and B at side, opposite	03	9	•	•	•	•	-	-	•	-	_	-	-	_	-	02
Threaded ports A and B	04	0	-	•	•	•	•	•	-	-	_	-	0	-	-	04
SAE flange ports	10	0	-	_	-	•	•	•	•	•	•	-	_	0	-	10
	17															17
	"	1	-	-	-	-	_	_	-	•	-					178
relief valves for mounting a	18	8	-	-	-	٠		•		•	•	-	-	-	-	18
counterbalance valve ⁵⁾ BVE	18	Ĩ	-	-	-	-	-	-	-	•	•	-	_ 4)	-	-	18
Port plate with	19	1	-	-	-	•	\bullet	•		•	•	-	-	-	-	19
pressure-relief valves		2	-	-	-	•	\bullet			•		-	-	-	-	19:
Flushing and boost pressure valve	, mou	inte		ity)					2 7							
	, mou nount	inte ed ^t	5)6)	ity)					2							
Flushing and boost pressure valve Counterbalance valve BVD/BVE r	, mou nount , integ	inte ed ^e gra	5)6)	ity)		5 t	:0 16	6 23	2 7 8	0 20	00 2	250 t	to 50	0 710 to	• 1000 ⁴⁾)
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve	, mou nount , integ d 43)	inte ed ^e gra	5)6)	ıty)		5 t	:o 16	6 23	2 7 8 9		00 : •	250 t	to 50	1	• 1000 ⁴⁾)
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an	, mou nount , integ d 43)	inte ed ^e gra	5)6)			5 t	-	6 23	2 7 8 9			250 t	to 50 •			
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co	, mou nount , integ d 43)	inte ed ^e gra	5)6)			5 t	-	6 23	2 7 8 9 8 to 18		•	250 t	to 50 •		•	F
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor	, mou nount , integ d 43)	inte ed ^e gra	5)6)			5 t	-	5 23	2 7 8 9 8 to 180			(to 50 • • •		•	F H U
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷⁾	, mou nount , integ d 43)	inte ed ^e gra	5)6)			5 t	-	6 23	2 7 8 9 9 8 to 18 • •				•		•	F
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷) Prepared for DSA speed sensor DSA speed sensor mounted ⁷)	, mou nount , integ d 43)	inte ed ^e gra	5)6)			5 t	-	6 23	2 7 8 9 8 to 18 • • •				• • • •		• - -	F H U
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷) Prepared for DSA speed sensor DSA speed sensor mounted ⁷) Special version	, mou nount , integ d 43)	inte ed ^e gra	5)6)			5 t	-	5 23	2 7 8 9 8 to 18 • • •				• • • •		• - -	F H U
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷) Prepared for DSA speed sensor DSA speed sensor mounted ⁷ Special version Standard version (without code)	, mou nount , integ d 43) de)	gra	5)6) ted		plate		-	6 23	2 7 8 9 8 to 18 • • •				• • • •		• - -	F H U
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷) Prepared for DSA speed sensor DSA speed sensor mounted ⁷) Special version Standard version (without code) Special version for slew drives (sta Standard / special version	, mou nount , integ d 43) de)	gra	5)6) ted		plate		-	5 23	2 7 8 9 8 to 18 • • •				• • • •		• - -	F H U
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷) Prepared for DSA speed sensor DSA speed sensor mounted ⁷) Special version Standard version (without code) Special version for slew drives (sta Standard / special version Standard version (without code)	, mou nount , integ d 43) de)	gra ^t	vith	port		÷ 19)	- - - -		2 7 8 9 3 to 18 0 				• • • •		• - -	F H U V
Flushing and boost pressure valve Counterbalance valve BVD/BVE r Flushing and boost pressure valve Speed sensors (see pages 42 an Without speed sensor (without co Prepared for HDD speed sensor HDD speed sensor mounted ⁷) Prepared for DSA speed sensor DSA speed sensor mounted ⁷) Special version Standard version (without code) Special version for slew drives (sta Standard / special version	, mou nount , integ d 43) de)	gra ^t	vith	port		÷ 19)	- - - -		2 7 8 9 3 to 18 0 				• • • •		• - -	F H U
	at side and rear ³⁾ SAE flange ports A and B at bottom (same side) Port plate BVD with 1-level pressure- relief valves for mounting a counterbalance valve ⁵⁾ BVE Port plate with pressure-relief valves Valves (see pages 34 to 41) Without valve Pressure-relief valve (without press	at side and rear ³⁾ SAE flange ports A and B at bottom (same side) Port plate With 1-level pressure- relief valves for mounting a counterbalance valve ⁵⁾ BVE 18 Port plate with 19 pressure-relief valves Valves (see pages 34 to 41) Without valve Pressure-relief valve (without pressure b	at side and rear3)0SAE flange ports10A and B at bottom (same side)0Port plateBVD17with 1-level pressure-18counterbalance valve5)BVE18Port plate with191pressure-relief valves2Valves (see pages 34 to 41)Vithout valve	at side and rear3)0-SAE flange ports100-A and B at bottom (same side)100-Port plateBVD171-relief valves for mounting a188-counterbalance valve ⁵⁾ BVE18-Port plate with191-pressure-relief valves2-Valves (see pages 34 to 41)Vithout valvePressure-relief valve (without pressure boost factors)-	at side and rear3)0-•SAE flange ports100A and B at bottom (same side)100Port plateBVD171with 1-level pressure-188relief valves for mounting a188counterbalance valve ⁵⁾ BVE181-Port plate with191pressure-relief valves2Valves (see pages 34 to 41)	at side and rear3)0- \bullet \bullet SAE flange ports100A and B at bottom (same side)0Port plateBVD171with 1-level pressure-188relief valves for mounting a188Counterbalance valve ⁵⁾ BVE18Port plate with191pressure-relief valves2Valves (see pages 34 to 41)Vithout valve	at side and rear3) U $ \bullet$ \bullet SAE flange ports A and B at bottom (same side)10 Port plate with 1-level pressure- relief valves for mounting a counterbalance valve5)10 BVD 0 $ -$ 8 $ -$ 9 Port plate with pressure-relief valves18 BVE18 BVE $ -$ 9 Port plate with pressure-relief valves19 2 1 $ -$ 9 Valves (see pages 34 to 41)19 V1 $ \bullet$	at side and rear3)0SAE flange ports100A and B at bottom (same side)0Port plateBVD171with 1-level pressure-188relief valves for mounting a188Port plate with191Port plate with191•pressure-relief valves2•Valves (see pages 34 to 41)+•	at side and rear3)0-••••SAE flange ports100•••A and B at bottom (same side)0•••Port plateBVD171with 1-level pressure-188relief valves for mounting a counterbalance valve ⁵⁾ BVE18Port plate with pressure-relief valves191••••Valves (see pages 34 to 41) 4444444	at side and rear3)0-•••-SAE flange ports A and B at bottom (same side)10 Port plate with 1-level pressure- relief valves for mounting a counterbalance valve5)10 BVE0 BVD 17 Port plate with 1-level pressure- relief valves for mounting a pressure-relief valves18 BVE18 Port plate Port plate with Port plate with Port plate with pressure-relief valves19 Port plate with Port plate with <b< td=""><td>at side and rear30SAE flange ports A and B at bottom (same side)10 Port plate with 1-level pressure- relief valves for mounting a counterbalance valve510 BVE08 9 relief valves for mounting a counterbalance valve518 BVE18 BVE<!--</td--><td>at side and rear30SAE flange ports A and B at bottom (same side)100Port plate with 1-level pressure- relief valves for mounting a counterbalance valve517 BVE17 BVE18 BVE8911 Port plate with pressure-relief valves19 BVE191911 Port plate with pressure-relief valves19 21000Valves (see pages 34 to 41)000</td><td>at side and rear3)0SAE flange ports100A and B at bottom (same side)0Port plateBVD171with 1-level pressure- relief valves for mounting a counterbalance valve⁵⁾188Port plate with pressure-relief valves191QPort plate with pressure-relief valves191Valves (see pages 34 to 41)00Without valve000</td><td>at side and rear3)0<</td><td>at side and rear30<t< td=""><td>at side and rear³⁾ 0 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -</td></t<></td></td></b<>	at side and rear30SAE flange ports A and B at bottom (same side)10 Port plate with 1-level pressure- relief valves for mounting a counterbalance valve510 BVE08 9 relief valves for mounting a counterbalance valve518 BVE18 BVE </td <td>at side and rear30SAE flange ports A and B at bottom (same side)100Port plate with 1-level pressure- relief valves for mounting a counterbalance valve517 BVE17 BVE18 BVE8911 Port plate with pressure-relief valves19 BVE191911 Port plate with pressure-relief valves19 21000Valves (see pages 34 to 41)000</td> <td>at side and rear3)0SAE flange ports100A and B at bottom (same side)0Port plateBVD171with 1-level pressure- relief valves for mounting a counterbalance valve⁵⁾188Port plate with pressure-relief valves191QPort plate with pressure-relief valves191Valves (see pages 34 to 41)00Without valve000</td> <td>at side and rear3)0<</td> <td>at side and rear30<t< td=""><td>at side and rear³⁾ 0 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -</td></t<></td>	at side and rear30SAE flange ports A and B at bottom (same side)100Port plate with 1-level pressure- relief valves for mounting a counterbalance valve517 BVE17 BVE18 BVE8911 Port plate with pressure-relief valves19 BVE191911 Port plate with pressure-relief valves19 21000Valves (see pages 34 to 41)000	at side and rear3)0SAE flange ports100A and B at bottom (same side)0Port plateBVD171with 1-level pressure- relief valves for mounting a counterbalance valve ⁵⁾ 188Port plate with pressure-relief valves191QPort plate with pressure-relief valves191Valves (see pages 34 to 41)00Without valve000	at side and rear3)0<	at side and rear 3 0 <t< td=""><td>at side and rear³⁾ 0 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -</td></t<>	at side and rear ³⁾ 0 - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -

4) Please contact us.

5) Note the restrictions on page 39.

6) Specify ordering code of counterbalance valve according to data sheet (BVD - RE 95522, BVE - RE 95525) separately.


7) Specify ordering code of sensor according to data sheet (DSA – RE 95133, HDD – RE 95135) separately and observe the requirements on the electronics

Hydraulic fluid

Before starting project planning, please refer to our data sheets RE 90220 (mineral oil), RE 90221 (environmentally acceptable hydraulic fluids), RE 90222 (HFD hydraulic fluids) and RE 90223 (HFA, HFB, HFC hydraulic fluids) for detailed information regarding the choice of hydraulic fluid and application conditions.

The fixed motor A2FM is not suitable for operation with HFA hydraulic fluid. If HFB, HFC or HFD or environmentally acceptable hydraulic fluids are used, the limitations regarding technical data or other seals must be observed.

Selection diagram



Viscosity and temperature of hydraulic fluid

Details regarding the choice of hydraulic fluid

The correct choice of hydraulic fluid requires knowledge of the operating temperature in relation to the ambient temperature: in a closed circuit, the circuit temperature, in an open circuit, the reservoir temperature.

The hydraulic fluid should be chosen so that the operating viscosity in the operating temperature range is within the optimum range (v_{opt} see shaded area of the selection diagram). We recommended that the higher viscosity class be selected in each case.

Example: At an ambient temperature of X °C, an operating temperature of 60 °C is set in the circuit. In the optimum operating viscosity range ($v_{opt.}$, shaded area), this corresponds to the viscosity classes VG 46 or VG 68; to be selected: VG 68.

Note

The case drain temperature, which is affected by pressure and speed, can be higher than the circuit temperature or reservoir temperature. At no point of the component may the temperature be higher than 115 °C. The temperature difference specified below is to be taken into account when determining the viscosity in the bearing.

If the above conditions cannot be maintained due to extreme operating parameters, we recommend flushing the case at port U (sizes 250 to 1000) or using a flushing and boost pressure valve (see pages 34).

	Viscosity [mm ² /s]	Temperature	Comment
Transport and storage at ambient temperature		$\begin{array}{l} T_{min} \geq -50 \ ^{o}C \\ T_{opt} = +5 \ ^{o}C \ to \ +20 \ ^{o}C \end{array}$	factory preservation: up to 12 months with standard, up to 24 months with long-term
(Cold) start-up ¹⁾	$v_{max} = 1600$	$T_{St} \ge -40 \ ^{\circ}C$	$ \begin{array}{l} t \leq 3 \text{ min, without load } (p \leq 50 \text{ bar}), \\ n \leq 1000 \text{ rpm (for sizes 5 to 200),} \\ n \leq 0.25 \bullet n_{nom} \text{ (for sizes 250 to 1000)} \end{array} $
Permissible temperature	difference	$\Delta T \le 25 \text{ K}$	between axial piston unit and hydraulic fluid
Warm-up phase	ν < 1600 to 400	T = -40 °C to -25 °C	at $p \leq 0.7$ • $p_{nom},n \leq 0.5$ • $n_{nom}andt \leq 15$ min
Operating phase			
Temperature difference		$\Delta T = approx. 12 K$	between hydraulic fluid in the bearing and at port T.
Maximum temperature		115 °C	in the bearing
		103 °C	measured at port T
Continuous operation	v = 400 to 10 $v_{opt} = 36 \text{ to } 16$	T = -25 °C to +90 °C	measured at port T, no restriction within the permissible data
Short-term operation ²⁾	$\nu_{min} \ge 7$	T _{max} = +103 °C	measured at port T, t < 3 min, p < 0.3 \bullet p_{nom}
FKM shaft seal ¹⁾		T ≤ +115 °C	see page 5

1) At temperatures below -25 °C, an NBR shaft seal is required (permissible temperature range: -40 °C to +90 °C).

2) Sizes 250 to 1000, please contact us.

Filtration of the hydraulic fluid

Finer filtration improves the cleanliness level of the hydraulic fluid, which increases the service life of the axial piston unit.

To ensure the functional reliability of the axial piston unit, a gravimetric analysis of the hydraulic fluid is necessary to determine the amount of solid contaminant and to determine the cleanliness level according to ISO 4406. A cleanliness level of at least 20/18/15 is to be maintained.

At very high hydraulic fluid temperatures (90 °C to maximum 115 °C), a cleanliness level of at least 19/17/14 according to ISO 4406 is necessary.

If the above classes cannot be achieved, please contact us.


Shaft seal


Permissible pressure loading


The service life of the shaft seal is influenced by the speed of the axial piston unit and the case drain pressure (case pressure). The mean differential pressure of 2 bar between the case and the ambient pressure may not be enduringly exceeded at normal operating temperature. For a higher differential pressure at reduced speed, see diagram. Momentary pressure spikes (t < 0.1 s) of up to 10 bar are permitted. The service life of the shaft seal decreases with an increase in the frequency of pressure spikes.

The case pressure must be equal to or higher than the ambient pressure.

Sizes 10 to 200







The values are valid for an ambient pressure $p_{abs} = 1$ bar.

Temperature range

The FKM shaft seal may be used for case drain temperatures from -25 °C to +115 °C.

Note

For application cases below -25 °C, an NBR shaft seal is required (permissible temperature range: -40 °C to +90 °C). State NBR shaft seal in plain text when ordering. Please contact us.

Direction of flow

Direction of rotation, viewed	on drive shaft
clockwise	counter-clockwise
A to B	B to A

Speed range

No limit to minimum speed n_{min} . If uniformity of motion is required, speed n_{min} must not be less than 50 rpm. See table of values on page 7 for maximum speed.

Long-life bearing

Sizes 250 to 1000

For long service life and use with HF hydraulic fluids. Identical external dimensions as motor with standard bearings. Subsequent conversion to long-life bearings is possible. Bearing and case flushing via port U is recommended.

Flushing flow (recommended)

NG	250	355	500	710	1000
q _{v flush} (L/min)	10	16	16	16	16

Operating pressure range

(operating with mineral oil)

Pressure at service line port A or B

Size 5

Nominal pressure pnom	_315 bar absolute
Maximum pressure pmax Single operating period Total operating period	350 bar absolute 10 s 300 h
Summation pressure (pressure A + pressu	re B) p _{Su} 630 bar
Sizes 10 to 200	
Nominal pressure p	100 bar absolute

Nominal pressure p _{nom}	400 bar absolute
Maximum pressure p _{max}	450 bar absolute
Single operating period	10 s

Summation pressure (pressure A + pressure B) p_{Su} _ 700 bar

Sizes 250 to 1000

Total operating period


Nominal pressure p _{nom}	350 bar absolute
Maximum pressure p _{max} Single operating period	400 bar absolute 10 s
Total operating period	300 h

Summation pressure (pressure A + pressure B) p_{Su} _ 700 bar

Minimum pressure (high-pressure side) ____25 bar absolute

Rate of pressure change RA max

with integrated pressure-relief valve_	9000 bar/s
without pressure-relief valve	16000 bar/s




Note

Values for other hydraulic fluids, please contact us.

Minimum pressure - pump mode (inlet)

To prevent damage to the axial piston motor in pump operating mode (change of high-pressure side with unchanged direction of rotation, e. g. when braking), a minimum pressure must be guaranteed at the service line port (inlet). The minimum pressure depends on the speed of the axial piston unit (see characteristic curve below).



This diagram is valid only for the optimum viscosity range from v_{opt} = 36 to 16 $\text{mm}^2/\text{s}.$

Please contact us if these conditions cannot be satisfied.

Definition

300 h

Nominal pressure pnom

The nominal pressure corresponds to the maximum design pressure.

Maximum pressure p_{max}

The maximum pressure corresponds to the maximum operating pressure within the single operating period. The sum of the single operating periods must not exceed the total operating period.

Minimum pressure (high-pressure side)


Minimum pressure at the high-pressure side (A or B) which is required in order to prevent damage to the axial piston unit.

Summation pressure pSu

The summation pressure is the sum of the pressures at both service line ports (A and B).

Rate of pressure change RA

Maximum permissible rate of pressure rise and reduction during a pressure change over the entire pressure range.



Total operating period = $t_1 + t_2 + ... + t_n$

Table of values (theoretical values, without efficiency and tolerances; values rounded)

Size		NG		5	10	12	16	23	28	32	45	56	63	80
Displacement per revolution	•	V_{g}	cm ³	4.93	10.3	12	16	22.9	28.1	32	45.6	56.1	63	80.4
Speed maxim	um ¹⁾	n _{nom}	rpm	10000	8000	8000	8000	6300	6300	6300	5600	5000	5000	4500
		n _{max} ²⁾	rpm	11000	8800	8800	8800	6900	6900	6900	6200	5500	5500	5000
Input flow ³⁾														
at n _{nom} and	Η V _g	q _V	L/min	49	82	96	128	144	177	202	255	281	315	362
Torque ⁴⁾														
at V_g and $\frac{1}{2}$	$\Delta p = 350 \text{ bar}$	Т	Nm	24.7 ⁵⁾	57	67	89	128	157	178	254	313	351	448
	$\Delta p = 400 \text{ bar}$	Т	Nm	-	66	76	102	146	179	204	290	357	401	512
Rotary stiffnes	ss	С	kNm/rad	0.63	0.92	1.25	1.59	2.56	2.93	3.12	4.18	5.94	6.25	8.73
Moment of ine rotary group	ertia for	J_{GR}	kgm²	0.00006	0.0004	0.0004	0.0004	0.0012	0.0012	0.0012	0.0024	0.0042	0.0042	0.0072
Maximum ang acceleration	Jular	α	rad/s ²	5000	5000	5000	5000	6500	6500	6500	14600	7500	7500	6000
Case volume		۷	L		0.17	0.17	0.17	0.20	0.20	0.20	0.33	0.45	0.45	0.55
Mass (approx.	.)	m	kg	2.5	5.4	5.4	5.4	9.5	9.5	9.5	13.5	18	18	23
Size		NG		90	107	125	160	180	200	250	355	500	710	1000
Displacement per revolution	-	V_{g}	cm ³	90	106.7	125	160.4	180	200	250	355	500	710	1000
Speed maxim					1000		3600	0000	0750	0700	0040	0000		1600
- 1	um ¹⁷	n _{nom}	rpm	4500	4000	4000	3600	3600	2750	2700	2240	2000	1600	1600
	um''		rpm rpm	4500 5000	4000	4000 4400	4000	4000	3000	-	-	-	1600 -	-
Input flow ³⁾	um''	n _{nom} n _{max} 2)												
•														
Input flow ³⁾		n _{max} ²⁾	rpm	5000	4400	4400	4000	4000	3000	_	_	_	_	-
Input flow ³⁾ at n _{nom} and Torque ⁴⁾		n _{max} ²⁾ q _V	rpm	5000	4400	4400	4000	4000	3000	_	_	_	_	-
Input flow ³⁾ at n _{nom} and Torque ⁴⁾ at V _g and 2	d V _g	n _{max} ²⁾ q _V T	rpm L/min	5000 405	4400 427	4400 500	4000 577	4000 648	3000 550	- 675	- 795	- 1000	- 1136	- 1600
Input flow ³⁾ at n _{nom} and Torque ⁴⁾ at V _g and 2	ΔV_g $\Delta p = 350 \text{ bar}$ $\Delta p = 400 \text{ bar}$	n _{max} ²⁾ q _V T	rpm L/min Nm	5000 405 501	4400 427 594	4400 500 696	4000 577 893	4000 648 1003	3000 550 1114	- 675 1393	- 795 1978	- 1000 2785	- 1136 3955	- 1600 5570
Input flow ³⁾ at n _{nom} and Torque ⁴⁾ at V _g and <u>4</u>	ΔV_g $\Delta p = 350 \text{ bar}$ $\Delta p = 400 \text{ bar}$ ss	n _{max} ²⁾ q _V T T	rpm L/min Nm Nm	5000 405 501 573 9.14	4400 427 594 679	4400 500 696 796 11.9	4000 577 893 1021 17.4	4000 648 1003 1146	3000 550 1114 1273	- 675 1393 - 73.1	- 795 1978 -	- 1000 2785 -	- 1136 3955 -	- 1600 5570 -
Input flow ³⁾ at n _{nom} and Torque ⁴⁾ at V _g and <u>4</u> Rotary stiffnes Moment of ine	ΔV_g $\Delta p = 350 \text{ bar}$ $\Delta p = 400 \text{ bar}$ ss ertia for	n _{max} ²⁾ q _V T T C	rpm L/min Nm Nm kNm/rad	5000 405 501 573 9.14	4400 427 594 679 11.2	4400 500 696 796 11.9	4000 577 893 1021 17.4	4000 648 1003 1146 18.2	3000 550 1114 1273 57.3	- 675 1393 - 73.1	- 795 1978 - 96.1 0.102	- 1000 2785 - 144	- 1136 3955 - 270	- 1600 5570 - 324
Input flow ³⁾ at n _{nom} and Torque ⁴⁾ at V _g and <u>4</u> Rotary stiffnes Moment of ine rotary group Maximum ang	ΔV_g $\Delta p = 350 \text{ bar}$ $\Delta p = 400 \text{ bar}$ ss ertia for	n _{max} ²⁾ q _V T T C J _{GR}	rpm L/min Nm Nm kNm/rad kgm ²	5000 405 501 573 9.14 0.0072	4400 427 594 679 11.2 0.0116	4400 500 696 796 11.9 0.0116	4000 577 893 1021 17.4 0.0220	4000 648 1003 1146 18.2 0.0220	3000 550 1114 1273 57.3 0.0353	- 675 1393 - 73.1 0.061	- 795 1978 - 96.1 0.102	- 1000 2785 - 144 0.178	- 1136 3955 - 270 0.55	- 1600 5570 - 324 0.55

1) The values are valid:

- for the optimum viscosity range from

 $v_{opt} = 36$ to 16 mm²/s

- with hydraulic fluid based on mineral oils

2) Intermittent maximum speed: overspeed for unload and overhauling processes, t < 5 s and Δp < 150 bar

- Restriction of input flow with counterbalance valve, see page 39
- 4) Torque without radial force, with radial force see page 8
- 5) Torque at $\Delta p = 315$ bar

Note

Operation above the maximum values or below the minimum values may result in a loss of function, a reduced service life or in the destruction of the axial piston unit. Other permissible limit values, with respect to speed variation, reduced angular acceleration as a function of the frequency and the permissible start up angular acceleration (lower than the maximum angular acceleration) can be found in data sheet RE 90261.

Permissible radial and axial forces of the drive shafts

(splined shaft and parallel keyed shaft)

(spined shart and para	-											
Size		NG		5	5 ³⁾	10	10	12	12	16	23	23
Drive shaft		Ø	mm	12	12	20	25	20	25	25	25	30
Maximum radial force ¹⁾		F _{q max}	kN	1.6	1.6	3.0	3.2	3.0	3.2	3.2	5.7	5.4
at distance a (from shaft collar)	a a	а	mm	12	12	16	16	16	16	16	16	16
with permissible torq		T _{max}	Nm	24.7	24.7	66	66	76	76	102	146	146
≙ permissible pressu	ıre ∆p	Δp_{perm}	bar	315	315	400	400	400	400	400	400	400
Maximum axial force ²⁾	∊₊₊₋╢	+F _{ax max}	Ν	180	180	320	320	320	320	320	500	500
	F _{ax} ±≓∈	-F _{ax max}	N	0	0	0	0	0	0	0	0	0
Permissible axial force per	bar operating pressure	±F _{ax perm/bar}	N/bar	1.5	1.5	3.0	3.0	3.0	3.0	3.0	5.2	5.2
Size		NG		28	28	32	45	56	56 ⁴⁾	56	63	80
Drive shaft		Ø	mm	25	30	30	30	30	30	35	35	35
Maximum radial force ¹⁾	, Fq , F q	F _{q max}	kN	5.7	5.4	5.4	7.6	9.5	7.8	9.1	9.1	11.6
at distance a (from shaft collar)		а	mm	16	16	16	18	18	18	18	18	20
with permissible torq	ue	T _{max}	Nm	179	179	204	290	357	294	357	401	512
≙ permissible pressu	ure ∆p	Δp_{perm}	bar	400	400	400	400	400	330	400	400	400
Maximum axial force ²⁾	- , fb	+F _{ax max}	Ν	500	500	500	630	800	800	800	800	1000
	Fax±≓≓⊟	-F _{ax max}	N	0	0	0	0	0	0	0	0	0
Permissible axial force per	bar operating pressure	$\pm F_{ax perm/bar}$	N/bar	5.2	5.2	5.2	7.0	8.7	8.7	8.7	8.7	10.6
Size		NG		80 ⁴⁾	80	90	107	107	125	160	160	180
Drive shaft		Ø	mm	35	40	40	40	45	45	45	50	50
Drive shaft Maximum radial force ¹⁾	,F _q	ø F _{q max}	mm kN	35 11.1	40 11.4	40 11.4	40 13.6	45 14.1	45 14.1	45 18.1	50 18.3	50 18.3
Maximum	Fq a			<u> </u>								
Maximum radial force ¹⁾ at distance a		F _{q max}	kN	11.1	11.4	11.4	13.6	14.1	14.1	18.1	18.3	18.3
Maximum radial force ¹⁾ at distance a (from shaft collar)	ue	F _{q max}	kN mm	11.1 20	11.4 20	11.4 20	13.6 20	14.1 20	14.1 20	18.1 25	18.3 25	18.3 25
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq	ue ure Δp	F _{q max} a T _{max} Δp _{perm}	kN mm Nm	11.1 20 488	11.4 20 512	11.4 20 573	13.6 20 679	14.1 20 679	14.1 20 796	18.1 25 1021	18.3 25 1021	18.3 25 1146
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu	ue	F _{q max} a T _{max}	kN mm Nm bar	11.120488380	11.420512400	11.4 20 573 400	13.6 20 679 400	14.1 20 679 400	14.1 20 796 400	18.1 25 1021 400	18.3 25 1021 400	18.3 25 1146 400
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu	$ \frac{1}{1} $ $ 1$	F _{q max} a T _{max} Δp perm +F _{ax max} -F _{ax max}	kN mm Nm bar N N	11.1 20 488 380 1000	11.4 20 512 400 1000	11.4 20 573 400 1000	13.6 20 679 400 1250	14.1 20 679 400 1250	14.1 20 796 400 1250	18.1 25 1021 400 1600	18.3 25 1021 400 1600	18.3 25 1146 400 1600
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq △ permissible pressu Maximum axial force ²⁾	$ \frac{1}{1} $ $ 1$	F _{q max} a T _{max} Δp perm +F _{ax max} -F _{ax max}	kN mm Nm bar N N	11.1 20 488 380 1000 0	11.4 20 512 400 1000 0	11.4 20 573 400 1000 0	13.6 20 679 400 1250 0	14.1 20 679 400 1250 0	14.1 20 796 400 1250 0	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu Maximum axial force ²⁾ Permissible axial force per	$ \frac{1}{1} $ $ 1$	Fq max a Tmax Δp perm +Fax max -Fax max ±Fax perm/bar	kN mm Nm bar N N	11.1 20 488 380 1000 0 10.6	11.4 20 512 400 1000 0 10.6	11.4 20 573 400 1000 0 10.6	13.6 20 679 400 1250 0 12.9	14.1 20 679 400 1250 0 12.9	14.1 20 796 400 1250 0 12.9	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft Maximum	$ \frac{1}{1} $ $ 1$	Fq max a Tmax Δp perm +Fax max -Fax max ±Fax perm/bar NG	kN mm bar N N N N/bar	11.1 20 488 380 1000 0 10.6 200	11.4 20 512 400 1000 0 10.6 250	11.4 20 573 400 1000 0 10.6 355	13.6 20 679 400 1250 0 12.9 500	14.1 20 679 400 1250 0 12.9 710	14.1 20 796 400 1250 0 12.9 12.9	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft	$ \frac{1}{1} $ $ 1$	$\begin{array}{c} F_{q \ max} \\ a \\ \hline T_{max} \\ \Delta p \ perm \\ + F_{ax \ max} \\ - F_{ax \ max} \\ \hline t F_{ax \ perm/bar} \\ \hline \textbf{NG} \\ \hline \textbf{0} \\ F_{q \ max} \\ a \end{array}$	kN mm bar N N N N/bar mm	11.1 20 488 380 1000 0 10.6 200 50	11.4 20 512 400 1000 0 10.6 250 5.0 1.2 ⁶⁾ 41	11.4 20 573 400 1000 0 10.6 355 60 1.5 ⁶⁾ 52.5	13.6 20 679 400 1250 0 12.9 70 1.9 ⁶⁾ 52.5	14.1 20 679 400 1250 0 12.9 710 90 3.0 ⁶⁾ 67.5	14.1 20 796 400 1250 0 12.9 12.9 90 2.6 ⁶) 67.5	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq △ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq	$F_{ax} \pm \pm e$ bar operating pressure F_{q} ue	Fq max a Tmax Δp perm +Fax max -Fax max ±Fax perm/bar MG Ø Fq max	kN mm bar N N N/bar M/bar kN	11.1 20 488 380 1000 0 10.6 200 50 20.3	11.4 20 512 400 1000 0 10.6 50 1.2 ⁶⁾ 41	11.4 20 573 400 1000 0 10.6 355 60 1.5 ⁶⁾ 52.5	13.6 20 679 400 1250 0 12.9 500 70 1.9 ⁶⁾ 52.5	14.1 20 679 400 1250 0 12.9 710 90 3.0 ⁶⁾ 67.5	14.1 20 796 400 1250 0 12.9 1000 90 2.6 ⁶ 67.5	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft Maximum radial force ¹⁾ at distance a (from shaft collar)	$F_{ax} \pm \pm e$ bar operating pressure F_{q} ue	$\begin{array}{c} F_{q \ max} \\ a \\ \hline T_{max} \\ \Delta p \ perm \\ + F_{ax \ max} \\ - F_{ax \ max} \\ \hline t F_{ax \ perm/bar} \\ \hline \textbf{NG} \\ \hline \textbf{0} \\ F_{q \ max} \\ a \end{array}$	kN mm bar N N N/bar M/bar mm kN	11.1 20 488 380 1000 0 10.6 200 50 20.3 25	11.4 20 512 400 1000 0 10.6 250 5.0 1.2 ⁶⁾ 41	11.4 20 573 400 1000 0 10.6 355 60 1.5 ⁶⁾ 52.5	13.6 20 679 400 1250 0 12.9 70 1.9 ⁶⁾ 52.5	14.1 20 679 400 1250 0 12.9 710 90 3.0 ⁶⁾ 67.5	14.1 20 796 400 1250 0 12.9 12.9 90 2.6 ⁶) 67.5	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq △ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq	$F_{ax} \pm \pm e$ bar operating pressure F_{q} ue	$\begin{array}{c} F_{q \ max} \\ a \\ \hline T_{max} \\ \Delta p \ perm \\ + F_{ax \ max} \\ - F_{ax \ max} \\ \hline x \\ F_{ax \ perm/bar} \\ \hline ng \\ \rho \\ F_{q \ max} \\ a \\ \hline T_{max} \end{array}$	kN mm bar N N N/bar Mm kN mm	11.1 20 488 380 1000 0 10.6 200 20.3 25 1273	11.4 20 512 400 1000 0 10.6 50 1.2 ⁶⁾ 41	11.4 20 573 400 1000 0 10.6 355 60 1.5 ⁶⁾ 52.5	13.6 20 679 400 1250 0 12.9 500 70 1.9 ⁶⁾ 52.5	14.1 20 679 400 1250 0 12.9 710 90 3.0 ⁶⁾ 67.5	14.1 20 796 400 1250 0 12.9 1000 90 2.6 ⁶ 67.5	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu	$F_{ax} \pm \pm e$ bar operating pressure F_{q} ue	$\begin{array}{c} F_{q \ max} \\ a \\ \\ T_{max} \\ \Delta p \ perm \\ +F_{ax \ max} \\ -F_{ax \ max} \\ \hline \\ F_{ax \ perm/bar} \\ \hline \\ \textbf{NG} \\ \textbf{0} \\ F_{q \ max} \\ a \\ \hline \\ T_{max} \\ \Delta p \ perm \end{array}$	kN mm bar N N N/bar kN kN mm kN Mm bar	11.1 20 488 380 1000 0 10.6 200 50 20.3 25 1273 400	11.4 20 512 400 1000 0 10.6 50 1.2 ⁶⁾ 41	11.4 20 573 400 1000 0 10.6 355 60 1.5 ⁶⁾ 52.5	13.6 20 679 400 1250 0 12.9 500 70 1.9 ⁶⁾ 52.5	14.1 20 679 400 1250 0 12.9 710 90 3.0 ⁶⁾ 67.5 5)	14.1 20 796 400 1250 0 12.9 12.9 90 2.6 ⁶⁾ 67.5	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0
Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu Maximum axial force ²⁾ Permissible axial force per Size Drive shaft Maximum radial force ¹⁾ at distance a (from shaft collar) with permissible torq ▲ permissible pressu	$F_{ax} \pm \pm f_{ax} \pm$	$\begin{array}{c} F_{q \ max} \\ a \\ \hline \\ T_{max} \\ \Delta p \ perm \\ + F_{ax \ max} \\ - F_{ax \ max} \\ \hline \\ E_{ax \ perm/bar} \\ \hline \\ NG \\ \hline \\ e_{q \ max} \\ \hline \\ a \\ \hline \\ T_{max} \\ \Delta p \ perm \\ + F_{ax \ max} \\ - F_{ax \ max} \\ \hline \\ - F_{ax \ max} \\ \hline \end{array}$	kN mm bar N N N/bar kN kN kN kN kN kN kN kN kN kN kN	11.1 20 488 380 1000 0 10.6 200 20.3 25 1273 400 1600	11.4 20 512 400 1000 0 10.6 50 1.2 ⁶⁾ 41	11.4 20 573 400 1000 0 10.6 355 60 1.5 ⁶⁾ 52.5	13.6 20 679 400 1250 0 12.9 500 70 1.9 ⁶⁾ 52.5 5) 5) 5)	14.1 20 679 400 1250 0 12.9 710 90 3.0 ⁶) 67.5 5) 5)	14.1 20 796 400 1250 0 12.9 12.9 90 2.6 ⁶ 67.5 5) 5)	18.1 25 1021 400 1600 0	18.3 25 1021 400 1600 0	18.3 25 1146 400 1600 0

1) With intermittent operation

2) Maximum permissible axial force during standstill or when the axial piston unit is operating in non-pressurized condition. 6) When at a standstill or when axial piston unit operating in non-pressurized conditions. Higher forces are permissible when under pressure, please contact us.
 Note

3) Conical shaft with threaded pin and woodruff key (DIN 6888)

4) Restricted technical data only for splined shaft

5) Please contact us.

Influence of the direction of the permissible axial force:


 $+F_{ax max}$ = Increase in service life of bearings

-F_{ax max} = Reduction in service life of bearings (avoid)

Effect of radial force F_q on the service life of bearings

By selecting a suitable direction of radial force F_q , the load on the bearings, caused by the internal rotary group forces can be reduced, thus optimizing the service life of the bearings. Recommended position of mating gear is dependent on direction of rotation. Examples:

	Toothed gear drive	V-belt output
NG	φopt	φopt
5 to 180	± 70°	± 45°
200 to 1000	± 45°	± 70°



Determining the operating characteristics

Input flow
$$q_v = \frac{V_g \cdot n}{1000 \cdot \eta_v}$$
 [L/min]

$$n = \frac{q_V \cdot 1000 \cdot \eta_v}{V_a} \qquad [min^{-1}]$$

$$T = \frac{V_{g} \cdot \Delta p \cdot \eta_{mh}}{20 \cdot \pi}$$
 [Nm]

$$\mathsf{P} = \frac{2 \pi \cdot \mathbf{T} \cdot \mathsf{n}}{60000} = \frac{\mathsf{q}_{\mathsf{v}} \cdot \Delta \mathsf{p} \cdot \eta_{\mathsf{t}}}{600} [\mathsf{kW}]$$

V_g = Displacement per revolution in cm³

- $\Delta p = Differential pressure in bar$
- n = Speed in rpm


Speed

Torque


Power

- η_v = Volumetric efficiency
- η_{mh} = Mechanical-hydraulic efficiency
- η_t = Total efficiency ($\eta_t = \eta_v \bullet \eta_{mh}$)

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard ⁶⁾	Size ³⁾	Maximum pressure [bar]4)	State ⁷⁾
A, B	Service line	DIN 3852	M18 x 1.5; 12 deep	350	0
T ₁	Drain line	DIN 3852	M10 x 1; 8 deep	3	0
T ₂	Drain line	DIN 3852	M10 x 1; 8 deep	3	0

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Thread according to DIN 3852, maximum tightening torque: 30 Nm

6) The spot face can be deeper than specified in the appropriate standard.


7) O = Must be connected (plugged on delivery)

Dimensions sizes 10, 12, 16

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
А, В	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M12 x 1.5; 12 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M12 x 1.5; 12 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)


1x O each

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

Dimensions sizes 10, 12, 16

Location of the service line ports on the port plates





1) Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

DIN 3852

3) The spot face can be deeper than specified in the appropriate standard.

Service line

4) O = Must be connected (plugged on delivery)

04


04 - Threaded ports at side and rear

M22 x 1.5; 14 deep


450

Dimensions sizes 23, 28, 32

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
A, B	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M16 x 1.5; 12 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M16 x 1.5; 12 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).


6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)


Dimensions sizes 23, 28, 32

Location of the service line ports on the port plates









10 - SAE flange ports at bottom (same side)⁴⁾




Plate	Designation	Port for	Standard	Size ¹⁾	Maximum pressure [bar] ²⁾	State ⁶⁾
01, 02, 10	А, В	Service line Fastening thread A/B	SAE J518 ³⁾ DIN 13	1/2 in M8 x 1.25; 15 deep	450	0
03]	Service line	DIN 3852 ⁵⁾	M27 x 2; 16 deep	450	0
04		Service line	DIN 3852 ⁵⁾	M27 x 2; 16 deep	450	1x O each

1) Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard

4) Only sizes 28 and 32


5) The spot face can be deeper than specified in the appropriate standard.


6) O = Must be connected (plugged on delivery)


Note

Port plates 18 and 19: see pages 37 and 40











Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
A, B	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Depending on installation position, T1 or T2 must be connected (see also installation instructions on page 44).


6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)

Dimensions size 45

Location of the service line ports on the port plates










02 - SAE flange ports at side, opposite



¹⁾ Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

4) The spot face can be deeper than specified in the appropriate standard.


5) O = Must be connected (plugged on delivery)

Note


Port plates 18 and 19: see pages 37 and 40

Dimensions sizes 56, 63

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
A, B	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).


6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)


Dimensions sizes 56, 63

Location of the service line ports on the port plates





02 - SAE flange ports at side, opposite



1) Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

4) The spot face can be deeper than specified in the appropriate standard.


5) O = Must be connected (plugged on delivery)

Note


Port plates 18 and 19: see pages 37 and 40

Dimensions sizes 80, 90

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
A, B	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).


6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)

Dimensions sizes 80, 90

Location of the service line ports on the port plates





10 – SAE flange ports at bottom (same side)




Plate	Designation	Port for	Standard	Size ¹⁾	Maximum pressure [bar] ²⁾	State ⁴⁾
01, 02, 10	, ,	Service line Fastening thread A/B	SAE J518 ³⁾ DIN 13	1 in M12 x 1.75; 17 deep	450	0

1) Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

4) O = Must be connected (plugged on delivery)


Note

Port plates 18 and 19: see pages 37 and 40


02 – SAE flange ports at side, opposite

Dimensions sizes 107, 125

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
A, B	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M18 x 1.5; 12 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).


6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)


Dimensions sizes 107, 125


Location of the service line ports on the port plates





02 - SAE flange ports at side, opposite (size 107)








Plate	Designation	Port for	Standard	Size ¹⁾	Maximum pressure [bar] ²⁾	State ⁴⁾
01, 10	А, В	Service line Fastening thread A/B	SAE J518 ³⁾ DIN 13	1 1/4 in M14 x 2; 19 deep	450	0
02 (size 107)		Service line Fastening thread A/B	SAE J518 ³⁾ DIN 13	1 in M12 x 1.75; 17 deep	450	0
02 (size 125)		Service line Fastening thread A/B	SAE J518 ³⁾ DIN 13	1 1/4 in M14 x 2; 19 deep	450	0

1) Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.


4) O = Must be connected (plugged on delivery)

Note


Port plates 17, 18 and 19: see pages 37 and 40

Dimensions sizes 160, 180

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
A, B	Service line (see port plates)			450	
T ₁	Drain line	DIN 3852 ⁶⁾	M22 x 1.5; 14 deep	3	X ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M22 x 1.5; 14 deep	3	O ⁵⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

6) The spot face can be deeper than specified in the appropriate standard.


7) O = Must be connected (plugged on delivery)


A

Before finalizing your design, request a binding installation drawing. Dimensions in mm.


Dimensions sizes 160, 180

Location of the service line ports on the port plates





10 - SAE flange ports at bottom (same side)



-		Detail Y
-	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	

02 - SAE flange ports at side, opposite

Plate	Designation	Port for	Standard	Size ¹⁾	Maximum pressure [bar] ²⁾	State ⁴⁾
01, 02, 10	А, В	Service line Fastening thread A/B	SAE J518 ³⁾ DIN 13	1 1/4 in M14 x 2; 19 deep	450	0

1) Observe the general instructions on page 46 for the maximum tightening torques

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.


4) O = Must be connected (plugged on delivery)

Note

Port plates 18 and 19: see pages 37 and 40

Port plate 01 - SAE flange ports at rear

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁸⁾
А, В	Service line Fastening thread A/B	SAE J5185 ⁾ DIN 13	1 1/4 in M14 x 2; 19 deep	450	0
T ₁	Drain line	DIN 38527)	M22 x 1.5; 14 deep	3	X ⁶⁾
T ₂	Drain line	DIN 38527)	M22 x 1.5; 14 deep	3	O ⁶⁾

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.


6) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

7) The spot face can be deeper than specified in the appropriate standard.


O = Must be connected (plugged on delivery)

Notes

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Drive shafts



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁷⁾
А, В	Service line (see port plates)			400	
T ₁	Drain line	DIN 3852 ⁶⁾	M22 x 1.5; 14 deep	3	O ⁵⁾
T ₂	Drain line	DIN 3852 ⁶⁾	M22 x 1.5; 14 deep	3	X ⁵⁾
U	Bearing flushing	DIN 3852 ⁶⁾	M14 x 1.5; 12 deep	3	Х

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.


5) Depending on installation position, T1 or T2 must be connected (see also installation instructions on page 44).

6) The spot face can be deeper than specified in the appropriate standard.

7) O = Must be connected (plugged on delivery)

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

Location of the service line ports on the port plates



1) Observe the general instructions on page 46 for the maximum tightening torques


2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

4) O = Must be connected (plugged on delivery)

Port plate 01 - SAE flange ports at rear

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ^{4)}	State ⁸⁾
A, B	Service line Fastening thread A/B	SAE J5185 ⁾ DIN 13	1 1/2 in M16 x 2; 21 deep	400	0
T ₁	Drain line	DIN 38527)	M33 x 2; 18 deep	3	O ⁶⁾
T ₂	Drain line	DIN 38527)	M33 x 2; 18 deep	3	X ⁶⁾
U	Bearing flushing	DIN 38527)	M14 x 1.5; 12 deep	3	Х
M _A , M _B	Measuring operating pressure	DIN 3852 ⁷⁾	M14 x 1.5; 12 deep	400	Х

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

6) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

7) The spot face can be deeper than specified in the appropriate standard.


O = Must be connected (plugged on delivery)

Port plate 01 - SAE flange ports at rear

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

40

130



Ports

67

80

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁸⁾
А, В	Service line Fastening thread A/B	SAE J5185 ⁾ DIN 13	1 1/2 in M16 x 2; 21 deep	400	0
T ₁	Drain line	DIN 3852 ⁷⁾	M33 x 2; 18 deep	3	O ⁶⁾
T ₂	Drain line	DIN 38527)	M33 x 2; 18 deep	3	X ⁶⁾
U	Bearing flushing	DIN 38527)	M18 x 1.5; 12 deep	3	Х
M _A , M _B	Measuring operating pressure	DIN 3852 ⁷⁾	M14 x 1.5; 12 deep	400	Х

880

105

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.


6) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

7) The spot face can be deeper than specified in the appropriate standard.

8) O = Must be connected (plugged on delivery)

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

Port plate 01 - SAE flange ports at rear



Ports

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁸⁾
A, B	Service line Fastening thread A/B	SAE J518 ⁵⁾ DIN 13	2 in M20 x 2.5; 30 deep	400	0
T ₁	Drain line	DIN 38527)	M42 x 2; 20 deep	3	O ⁶⁾
T ₂	Drain line	DIN 38527)	M42 x 2; 20 deep	3	X ⁶⁾
U	Bearing flushing	DIN 3852 ⁷⁾	M18 x 1.5; 12 deep	3	Х
M _A , M _B	Measuring operating pressure	DIN 3852 ⁷⁾	M14 x 1.5; 12 deep	400	Х

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

6) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

7) The spot face can be deeper than specified in the appropriate standard.


O = Must be connected (plugged on delivery)

Port plate 01 - SAE flange ports at rear

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

50

170



Ports

91

105

Designation	Port for	Standard	Size ³⁾	Maximum pressure [bar] ⁴⁾	State ⁸⁾
А, В	Service line Fastening thread A/B	SAE J518 ⁵⁾ DIN 13	2 in M20 x 2.5; 30 deep	400	0
T ₁	Drain line	DIN 38527)	M42 x 2; 20 deep	3	O ⁶⁾
T ₂	Drain line	DIN 38527)	M42 x 2; 20 deep	3	X ⁶⁾
U	Bearing flushing	DIN 3852 ⁷⁾	M18 x 1.5; 12 deep	3	Х
M _A , M _B	Measuring operating pressure	DIN 3852 ⁷⁾	M14 x 1.5; 12 deep	400	Х

1) To shaft collar

2) Center bore according to DIN 332 (thread according to DIN 13)

3) Observe the general instructions on page 46 for the maximum tightening torques.

4) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

5) Only dimensions according to SAE J518, metric fastening thread is a deviation from standard.

6) Depending on installation position, T₁ or T₂ must be connected (see also installation instructions on page 44).

130

7) The spot face can be deeper than specified in the appropriate standard.

8) O = Must be connected (plugged on delivery)

Flushing and boost pressure valve

The flushing and boost pressure valve is used to remove heat from the hydraulic circuit.

In an open circuit, it is used only for flushing the housing.

In a closed circuit, it ensures a minimum boost pressure level in addition to the case flushing.

Hydraulic fluid is directed from the respective low pressure side into the motor housing. This is then fed into the reservoir, together with the case drain fluid. The hydraulic fluid, removed out of the closed circuit must be replaced by cooled hydraulic fluid from the boost pump.

With port plate 027, the valve is mounted directly on the fixed motor (sizes 45 to 180, 250); with port plate 017 (sizes 355 and 500) on a plate.

Cracking pressure of pressure retaining valve

(observe when setting the primary valve) Sizes 45 to 500, fixed setting

Switching pressure of flushing piston Δp		
Sizes 45 to 500	8±1	bar


Flushing flow q_v

Orifice (throttles with integrated valve) can be used to set the flushing flows as required.

Following parameters are based on:

 $\Delta p_{ND} = p_{ND} - p_G = 25$ bar and v = 10 mm²/s ($p_{ND} = low$ pressure, $p_G = case$ pressure)

Schematic



Standard flushing flows

16 bar

Flushing and boost pressure valve, mounted (code 7)

Size	Flushing flow q _v [L/min]	ø [mm]	Mat. No. of orifice
45	3.5	1.2	R909651766
107, 125	8	1.8	R909419696
160, 180	10	2.0	R909419697
250	10	2.0	R909419697
355, 500	16	2.5	R910803019

With sizes 45 to 180, orifices can be supplied for flushing flows from 3.5 to 10 L/min. For other flushing flows, please state the required flushing flow when ordering. The flushing flow without orifice is approx. 12 to 14 L at low pressure $\Delta p_{ND} = 25$ bar.


Flushing and boost pressure valve, integrated (code 9)

Size	Throttle ø [mm]	q _v [L/min]
56, 63,	1.5	6
80, 90	1.8	7.3

Flushing and boost pressure valve


Dimensions

Port plate 027 - SAE flange ports at side




Size	A1	A2
45	223	151
107, 125	294	192
160, 180	315	201
250	344	172

Port plate 029 -	SAE flange	ports at side
------------------	------------	---------------



Size	A1	A2	
56, 63	225	176	
80, 90	257	186.7	

Port plate 017 - SAE flange ports at rear



1) DIN 13, observe the general instructions on page 46 for the maximum tightening torques

Pressure-relief valve

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

The MHDB pressure-relief valves (see RE 64642) protect the hydraulic motor from overload. As soon as the set cracking pressure is reached, the hydraulic fluid flows from the high-pressure side to the low-pressure side.

The pressure-relief valves are only available in combination with port plates 181, 191 or 192 (counterbalance valve for mounting to port plate 181: see next page).


Cracking pressure setting range _____ 50 to 420 bar

With the version "with pressure boost facility" (192), a higher pressure setting can be realized by applying an external pilot pressure of 25 to 30 bar to port P_{St} .


When ordering, please state in plain text:

- Cracking pressure of pressure-relief valve
- Cracking pressure with pilot pressure applied to P_{St} (only with version 192)

Version without pressure boost facility "191"




Version with pressure boost facility "192"



Pressure-relief valve

Dimensions

Before finalizing your design, request a binding installation drawing. Dimensions in mm.



Assembly instructions for port plate with pressure boost facility "192":

The lock nut must be counterheld when installing the hydraulic line at the pst port!

M26 x 1.5; 16 deep

Ports

56, 63

80, 90

107, 125

160, 180

Designation	Port for	Standard	Size	Maximum pressure [bar] ²⁾	State ³⁾
А, В	Service line	SAE J518	See above	450	0
S ₁	Supply (only with port plate 191/192)	DIN 3852	See above	5	0
M _A , M _B	Measuring operating pressure	DIN 3852	See above	450	Х
P _{St}	Pilot pressure (only with port plate 192)	DIN ISO 228	See above	30	0

M26 x 1.5; 16 deep

M26 x 1.5; 16 deep

M26 x 1.5; 16 deep

M30 x 1.5; 16 deep

G 1/4

G 1/4 G 1/4

G 1/4

1) Observe the general instructions on page 46 for the maximum tightening torques.

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

O = Must be connected (plugged on delivery)

3/4 in

1 1/4 in

1 1/4 in

1 in

Counterbalance valve BVD and BVE

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

Function

Travel drive/winch counterbalance valves are designed to reduce the danger of overspeeding and cavitation of axial piston motors in open circuits. Cavitation occurs if the motor speed is greater than it should be for the given input flow while braking, travelling downhill, or lowering a load.

If the inlet pressure drops, the counterbalance spool throttles the return flow and brakes the motor until the inlet pressure returns to approx. 20 bar.

Note


- BVD available for sizes 28 to 180 and BVE available for sizes 107 to 180.
- The counterbalance valve must be ordered additionally. We recommend ordering the counterbalance valve and the motor as a set. Ordering example: A2FM90/61W-VAB188 + BVD20F27S/41B-V03K16D0400S12
- The counterbalance valve does not replace the mechanical service brake and park brake.
- Observe the detailed notes on the BVD counterbalance valve in RE 95522 and BVE counterbalance valve in RE 95525!
- For the design of the brake release valve, we must know for the mechanical park brake:
 - the pressure at the start of opening
 - the volume of the counterbalance spool between minimum stroke (brake closed) and maximum stroke (brake released with 21 bar)
 - the required closing time for a warm device (oil viscosity approx. 15 mm²/s)

Travel drive counterbalance valve BVD...F

Application option

- Travel drive on wheeled excavators

Example schematic for travel drive on wheeled excavators A2FM090/61W-VAB188 + BVD20F27S/41B-V03K16D0400S12




Counterbalance valve BVD and BVE

Winch counterbalance valve BVD...W and BVE

Application options

- Winch drive in cranes (BVD and BVE)
- Track drive in excavator crawlers (BVD)

Example schematic for winch drive in cranes A2FM090/61W-VAB188 + BVE25W385/51ND-V100K00D4599T30S00-0



Permissible input flow or pressure in operation with DBV and BVD/BVE


	Without val	ve	Restricted v	Restricted values in operation with DBV and				BVD/BVE			
Motor			DBV				BVD/BVE				
NG	p _{nom} /p _{max} [bar]	q _{V max} [L/min]	NG	p _{nom} /p _{max} [bar]	q _v [L/min]	Code	NG	p _{nom} /p _{max} [bar]	q _v [L/min]	Code	
28	400/450	176	16	350/420	100	181	20	350/420	100	188	
32		201				191, 192	(BVD)				
45		255									
56		280	22		240				220		
63		315									
80		360									
90		405									
107		427				171				178	
125		500				191, 192					
107		427	32		400	181	25		320	188	
125		500				191, 192	(BVD/BVE)				
160		577									
180		648									
DBV			pres	sure-relief val	ve						

BVD _____counterbalance valve, double-acting

BVE _____counterbalance valve, one-sided

Counterbalance valve BVD and BVE

Dimensions



A2FM	Counterbalar	Counterbalance valve								
Size	Туре	Ports	Dimen	sions						
		А, В	B1	B2	B3	B4 (S)	B4 (L)	B5	B6	B7
28, 32	BVD 20 16	3/4 in	209	175	174	142	147	139	98	66
45	BVD 20 16	3/4 in	222	196	187	142	147	139	98	66
56, 63	BVD 20 17	3/4 in	250	197	208	142	147	139	98	75
80, 90	BVD 20 27	1 in	271	207	229	142	147	139	98	75
107, 125	BVD 20 28	1 in	298	238	251	142	147	139	98	84
107, 125	BVD 25 38	1 ¹ / ₄ in	298	239	251	158	163	175	120.5	84
160, 180	BVD 25 38	1 ¹ / ₄ in	332	260	285	158	163	175	120.5	84
107, 125	BVE 25 38	1 ¹ / ₄ in	298	240	251	167	172	214	137	84
160, 180	BVE 25 38	1 ¹ / ₄ in	332	260	285	167	172	214	137	84
250					On requ	est				

Ports

Designation	Port for	Version	Standard	Size ¹⁾	Maximum pressure [bar] ²⁾	State ⁴⁾
А, В	Service line		SAE J518	see table above	420	0
S	Infeed	BVD20	DIN 3852 ³⁾	M22 x 1.5; 14 deep	30	Х
		BVD25, BVE25	DIN 3852 ³⁾	M27 x 2; 16 deep	30	Х
Br	Brake release, reduced high pressure	L	DIN 3852 ³⁾	M12 x 1.5; 12.5 deep	30	0
G _{ext}	Brake release, high pressure	S	DIN 3852 ³⁾	M12 x 1.5; 12.5 deep	420	х
$M_{A,}M_{B}$	Measuring pressure A and B		ISO 6149 ³⁾	M12 x 1.5; 12 deep	420	Х

1) Observe the general instructions on page 46 for the maximum tightening torques.

2) Momentary pressure spikes may occur depending on the application. Keep this in mind when selecting measuring devices and fittings.

3) The spot face can be deeper than specified in the appropriate standard.

4) O = Must be connected (plugged on delivery)

Counterbalance valve BVD and BVE

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

Mounting the counterbalance valve


When delivered, the counterbalance valve is mounted to the motor with two tacking screws (transport protection). The tacking screws may not be removed while mounting the service lines. If the counterbalance valve and motor are delivered separately, the counterbalance valve must first be mounted to the motor port plate using the provided tacking screws. The counterbalance valve is finally mounted to the motor by screwing on the SAE flange with the following screws:

6 screws (1, 2, 3, 4, 5, 8)	length B1+B2+B3
2 screws (6, 7)	length B3+B4

Tighten the screws in two steps in the specified sequence from 1 to 8 (see following scheme).

In the first step, the screws must be tightened with half the tightening torque, and in the second step with the maximum tightening torque (see following table).

Thread	Strength class	Tightening torque [Nm]
M6 x 1 (tacking screw)	10.9	15.5
M10	10.9	75
M12	10.9	130
M14	10.9	205



Size	28, 32, 45	56, 63	80, 90	107, 125, 160, 180	107, 125
Port plate	18				17
B1 ¹⁾	M10 x 1.5; 17 deep	M10 x 1.5; 17 deep	M12 x 1.75; 18 deep	M14 x 2; 19 deep	M12 x 1.75; 17 deep
B2	78 ²⁾	68	68	85	68
B3	customer-specific				
B4	M10 x 1.5; 15 deep	M10 x 1.5; 15 deep	M12 x 1.75; 16 deep	M14 x 2; 19 deep	M12 x 1.75; 17 deep

1) Minimum required thread reach 1 x ø-thread

2) Including sandwich plate

Speed sensors

The versions A2FM...U and A2FM...F ("prepared for speed sensor", i.e. without sensor) is equipped with a toothed ring on the rotary group.

On deliveries "prepared for speed sensor", the port is plugged with a pressure-resistant cover.

With the DSA or HDD speed sensor mounted a signal proportional to motor speed can be generated.

The sensors measures the speed and direction of rotation.

Ordering code, technical data, dimensions and details on the connector, plus safety information about the sensor can be found in the relevant data sheet.

DSA	 RE 95133

HDD	RE 35135

The sensor is mounted at the specially provided port D as follows:


DSA ______with one mounting bolt

HDD ______ with two mounting bolts

We recommend ordering the A2FM fixed motor complete with sensor mounted.

Version "V"

Sizes 23 to 200 with DSA sensor





Version "V"

Sizes 250 to 500 with DSA sensor


On request

Version "H"





View X



Speed sensors

Before finalizing your design, request a binding installation drawing. Dimensions in mm.

Size			23, 28, 32	45	56, 63	80, 90	107, 125
Numbe	Number of teeth			45	47	53	59
DSA	Α	Insertion depth (tolerance \pm 0.1)	18.4	18.4	18.4	18.4	18.4
	В	Contact surface	57.9	64.9	69.9	74.9	79.9
	С		74.5	81.5	86.5	91.5	96.5
	D		54.7	54.3	61.5	72.5	76.8
Size			160, 180	200	250	355	500
Numbe	r of te	eeth	67	80	78	90	99
HDD	А	Insertion depth (tolerance \pm 0.1)	-	-	32	32	32
	В	Contact surface	-	-	110.5	122.5	132.5
	С		-	-	149	161	171
	D		-	-	82	93	113
DSA	Α	Insertion depth (tolerance \pm 0.1)	18.4	18.4	32	32	32
	В	Contact surface	87.4	100.9	_	-	_
	С		104	117.5	_	-	_
	D		86.8	97.5			

Installation instructions

General

During commissioning and operation, the axial piston unit must be filled with hydraulic fluid and air bled. This must also be observed following a relatively long standstill as the axial piston unit may drain back to the reservoir via the hydraulic lines.

Particularly in the installation position "drive shaft upwards" filling and air bleeding must be carried out completely as there is, for example, a danger of dry running.

The case drain fluid in the motor housing must be directed to the reservoir via the highest available drain port (T_1, T_2) .

For combinations of multiple units, make sure that the respective case pressure in each unit is not exceeded. In the event of pressure differences at the drain ports of the units, the shared drain line must be changed so that the minimum permissible case pressure of all connected units is not exceeded in any situation. If this is not possible, separate drain lines must be laid if necessary.

To achieve favorable noise values, decouple all connecting lines using elastic elements and avoid above-reservoir installation.

In all operating conditions, the drain line must flow into the reservoir below the minimum fluid level.

Installation position

See the following examples 1 to 8.

Further installation positions are possible upon request.

Recommended installation positions: 1 and 2.

Note

With sizes 10 to 200 with installation position "shaft upward", an air-bleed port R is required (state in plain text when ordering - special version). With sizes 250 to 1000, port U is provided as standard in the area near the bearings for air bleeding.

Installation position	Air bleed	Filling	
1	-	T ₁	
2	-	T ₂	
3	-	T ₁	
4	R (U)	T ₂	
5	L ₁	T ₁ (L ₁)	
6	L ₁	T ₂ (L ₁)	
7	L ₁	T ₁ (L ₁)	
8	R (U)	T ₂ (L ₁)	


L1 Filling / air bleed

- R Air bleed port (special version)
- U Bearing flushing / air bleed port
- T₁, T₂ Drain port
- ht min Minimum required immersion depth (200 mm)

h_{min} Minimum required spacing to reservoir bottom (100 mm)

Below-reservoir installation (standard)


Below-reservoir installation means that the axial piston unit is installed outside of the reservoir below the minimum fluid level.



Above-reservoir installation

Above-reservoir installation means that the axial piston unit is installed above the minimum fluid level of the reservoir.

Recommendation for installation position 8 (drive shaft upward): A check valve in the drain line (cracking pressure 0.5 bar) can prevent draining of the motor housing.



General instructions

- The motor A2FM is designed to be used in open and closed circuits.
- The project planning, installation and commissioning of the axial piston unit requires the involvement of qualified personnel.
- Before using the axial piston unit, please read the corresponding instruction manual completely and thoroughly. If necessary, these can be requested from Bosch Rexroth.
- During and shortly after operation, there is a risk of burns on the axial piston unit. Take appropriate safety measures (e. g. by wearing protective clothing).
- Depending on the operating conditions of the axial piston unit (operating pressure, fluid temperature), the characteristic may shift.
- Service line ports:
 - The ports and fastening threads are designed for the specified maximum pressure. The machine or system manufacturer must ensure that the connecting elements and lines correspond to the specified application conditions (pressure, flow, hydraulic fluid, temperature) with the necessary safety factors.
 - The service line ports and function ports can only be used to accommodate hydraulic lines.

- The data and notes contained herein must be adhered to.
- The product is not approved as a component for the safety concept of a general machine according to ISO 13849.
- The following tightening torques apply:
 - Fittings:

Observe the manufacturer's instructions regarding tightening torques of the fittings used.

- Mounting bolts:

For mounting bolts with metric ISO thread according to DIN 13 or with thread according to ASME B1.1, we recommend checking the tightening torque in individual cases in accordance with VDI 2230.

- Female threads in the axial piston unit: The maximum permissible tightening torques M_{G max} are maximum values for the female threads and must not be exceeded. For values, see the following table.
- Threaded plugs:

For the metallic threaded plugs supplied with the axial piston unit, the required tightening torques of threaded plugs M_V apply. For values, see the following table.

Ports		Maximum permissible tight-	· ·	WAF
Standard	Size of thread	ening torque of the female threads M _{G max}	tightening torque of the threaded plugs M _V ¹⁾	hexagon socket of the threaded plugs
M M	M10 x 1	30 Nm	15 Nm ²⁾	5 mm
	M12 x 1.5	50 Nm	25 Nm ²⁾	6 mm
	M14 x 1.5	80 Nm	35 Nm	6 mm
	M16 x 1.5	100 Nm	50 Nm	8 mm
	M18 x 1.5	140 Nm	60 Nm	8 mm
	M20 x 1.5	170 Nm	80 Nm	10 mm
	M22 x 1.5	210 Nm	80 Nm	10 mm
	M26 x 1.5	230 Nm	120 Nm	12 mm
	M27 x 2	330 Nm	135 Nm	12 mm
	M30 x 2	420 Nm	215 Nm	17 mm
	M33 x 2	540 Nm	225 Nm	17 mm
	M42 x 2	720 Nm	360 Nm	22 mm
DIN ISO 228	G 1/4	40 Nm	_	-

The tightening torques apply for screws in the "dry" state as received on delivery and in the "lightly oiled" state for installation.
 In the "lightly oiled" state, the M_V is reduced to 10 Nm for M10 x 1 and 17 Nm for M12 x 1.5.

Bosch Rexroth AG Mobile Applications Glockeraustrasse 4 An den 1 89275 Elchingen, Germany 72160 H Tel.: +49-7308-82-0 Tel.: +49 Fax: +49-7308-72-74 Fax: +49 info.brm@boschrexroth.de www.boschrexroth.de

An den Kelterwiesen 14 72160 Horb, Germany Tel.: +49-7451-92-0 Fax: +49-7451-82-21 © This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth AG. It may not be reproduced or given to third parties without its consent.

The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

Subject to change.